








































































### Torch






To switch on the torch:


1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until “Organiser” appears.  
Press the  GREEN key
3. Press  Up or Down navigation key until “Torch” appears.  
Press the  GREEN key.

Here you can switch on and off the flashlight. You can also hold down the 0 key for 3 seconds when in standby mode, press and hold it again to switch off the torch

### Alarm

You can set up to three alarms:



1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until “Organiser” appears.  
Press the  GREEN key.
3. Press  Up or Down navigation key until “Alarm” appears.  
Press the  GREEN key.

Choose one of the three available alarms and press the  GREEN key to see the options menu, use this menu to

switch on the alarm, set the time, set the tone and set the repeat options.






## **Turning off the Alarm**

When the alarm sounds:






- Press the  GREEN key to shut off the alarm
- Press the  RED key to snooze.



## Calendar

To view the calendar:



1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until "Organiser" appears.  
Press the  GREEN key.
3. Press  Up or Down navigation key until "Calendar" appears.  
Press the  GREEN key.

## Calculator

1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until "Organiser" appears.  
Press the  GREEN key
3. Press  Up or Down navigation key until "Calculator" appears.  
Press the  GREEN key






Enter number keys to enter values. Press the  star key for decimals. Use the  up or down navigation keys to select




the math operation: +, -, X, and ÷. Press the  RED key to clear the last digit or to exit the calculation operation. Press the  GREEN key to complete the calculation.

## My Files

The default file manager is your MicroSD memory card (not included, must be purchased separately).

1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until "Organiser" appears.  
Press the  GREEN key.
3. Press  Up or Down navigation key until "My Files" appears.  
Press the  GREEN key.
4. Choose either the Phone memory or the Memory card (MicroSD card).

Press the  GREEN key to enter the submenus to view or play multimedia files.

## Bluetooth



The mobile phone supports Bluetooth function. You can use Bluetooth wireless technology to set wireless connection with other compatible devices, including mobile phones, computers, headsets, in-car accessories etc. With Bluetooth function, you can send photos, video segments, audio segments, personal business card and memos. You can also establish wireless connection with a

compatible PC to transmit files.


Try to keep the two devices you are connecting through Bluetooth close together while they are in use. Most Bluetooth headsets have a range of 10 meters. If possible, try to keep your phone on a chair beside you or nearby while talking on your headset to ensure the best connection. When using your computer, try putting your phone on the desk beside your monitor to ensure the best connection possible.

### **Pair Bluetooth Devices**


Have one of the devices “search for new devices” to find the other. Typically you want a phone to search for your headset or audio speaker rather than the other way around. The Search function is located within the Bluetooth menu in the Organiser menu in your phone.

1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until “Organiser” appears.

Press the  GREEN key

3. Press  Up or Down navigation key until “Bluetooth” appears.

Press the  GREEN key

Press the  GREEN key to activate Bluetooth then use this menu to pair devices, make your phone discoverable and edit your device name.








Once your phone finds the other device enter the

“pairing code” for the device to link the two together. The pairing code is typically located on a sticker on the back of a headset or in the instruction book for a device.

## 12. Customizing Your Settings

### Profiles

You can use profiles to set and customise the ring tones, message alert tones, and other tones for different events.










1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until “Settings” appears.  
Press the  GREEN key.
3. Press  Up or Down navigation key until “Profiles” appears.  
Press the  GREEN key.
4. Use the  up and down navigation key to select from the following profiles:
  - Normal
  - Silent
  - Meeting
  - Indoor
  - Outdoor
  - Driving Mode
5. Press the  GREEN key to enter the editing mode.

Here you can Activate or change the Settings for each profile according to the items in the table below.

## Settings Menu


Setting	Description
Rename	Change the name of the profile
Ring Settings	Change the ringtone and message tone
Adjust volume	Change the volume for Calls, Messages and Alarms
Ring Type	Change the Vibrate settings
Other alert rings	Change the Keytone, Dialp pad tones, Battery low tones etc

### Turning Off Talking Buttons (Keypad Tone)


1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until "Settings" appears.  
Press the GREEN key.
3. Press  Up or Down navigation key until "Profiles" appears.  
Press the  GREEN key.
4. Use the  up and down navigation key to select the Normal profile  
Press the  GREEN key.
5. Press  Up or Down navigation key until "Settings" appears.  
Press the  GREEN key.
6. Press  Up or Down navigation key until "Other


alert rings” appears.

Press the  GREEN key.

7. Press  Up or Down navigation key until “Dial pad tone” appears.

Press the  GREEN key twice.

8. Use the  Up and Down navigation keys to select the tone you desire (Silent, Click, Tone or Human Voice)






Press the  GREEN key to save.

## Call Settings

These features require the support of your network provider based on the calling package you select when you purchase your phone.

Network Selection	Auto or Manual select your network
Call divert	Divert calls to another number *your network may charge for this service
Call waiting	Activate call waiting services
Call barring	Restrict numbers you will call or accept calls from.
Hide ID	Hide your phone number *network must support for this feature to work
Others	Auto redial, Call time minute reminder, Reply SMS after rejecting calls, Record voice calls, Vibration when connected.

## To access the Call Setting menu

1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until “Settings” appears.  
Press the  GREEN key.
3. Press  Up or Down navigation key until “Call settings” appears.  
Press the  GREEN key.

## Phone Lock

The phone lock can prevent your mobile phone from illegal use. You can set the phone lock as On or Off and change the phone password.

Phone lock can be found in the menu Settings/Security/Phone Lock - Press the GREEN key to access the Phone lock and input the password again to disable phone lock.





**Note: The default phone lock password is 1122. Please change into your own private password as soon as possible.**

## Restore to factory Settings

Press password 1122 to restore the default setting.

## Call logs

This option stores recently dialled calls, received calls and missed calls. Your phone can store up to 20 records for each function.

1. Press the  Up navigation key to access the menu.
2. Press  Up or Down navigation key until “Call logs” appears.  
Press the  GREEN key.
3. Scroll through available functions (missed calls, dialled calls, received calls, delete all).  
Press the  GREEN key to select the desired function.

## 13. Troubleshooting

Problems	Solutions
Phone does not turn on	<ol style="list-style-type: none"><li>1. Ensure you have held the power button down for more than 5 seconds.</li><li>2. Re-insert the battery and retry turning on the phone.</li><li>3. Plug charger into the phone and ensure the battery is charged.</li></ol>
Cannot connect to a network	<ol style="list-style-type: none"><li>1. Signal strength may be weak, try moving your location and try again.</li><li>2. It may be possible that you are using the phone beyond the network service coverage area.</li><li>3. Check that your SIM card is correctly installed and is valid. (Contact your network provider)</li></ol>
No information displays when the phone is on	<ol style="list-style-type: none"><li>1. Check that your SIM card is correctly installed.</li><li>2. You may need to unlock your keypad using the button on the side of the phone or your keypad (Password maybe required).</li><li>3. You may have permanently locked your phone by entering the PIN code incorrectly 3 times. Obtain your PIN code from your network provider.</li><li>4. Increase the screen brightness in "Settings".</li></ol>



Phone call quality is poor	<ol style="list-style-type: none"> <li>1. Increase the call volume using the key on the side of the phone.</li> <li>2. It may be that the network reception is poor in your location. Try moving to another area to obtain a better connection.</li> </ol>
Shorter standby time	<ol style="list-style-type: none"> <li>1. Standby time is related to system settings. In areas of poor reception, the phone will use more battery power to try to find a base station. Reduce the standby time to save battery power.</li> <li>2. It could also be the case that the battery of the phone has become worn out. You may need to replace the battery.</li> </ol>
SIM card Error	<ol style="list-style-type: none"> <li>1. Reinstall the SIM card in the phone. Ensure the metal contacts are clean - wipe gently with a clean cloth before inserting into the phone.</li> <li>2. The SIM card may not be correctly installed.</li> <li>3. If the SIM card is damaged contact your service provider.</li> </ol>
Some features do not operate or cannot be set	<ol style="list-style-type: none"> <li>1. This could be due to an operation error on the phone. Switch the mobile phone off and restart after 30 seconds.</li> <li>2. The network provider may not support the feature you are trying to use and this may prevent its use.</li> </ol>

Cannot receive incoming calls	<ol style="list-style-type: none"> <li>1. Ensure your mobile phone is switched on and connected to a network.</li> <li>2. Ensure your SIM card is correctly installed.</li> <li>3. Call restrictions may be prohibiting incoming phone calls, so these settings must be checked.</li> <li>4. Poor areas of network coverage can prevent incoming calls so check the network status of your phone.</li> </ol>
Phone not charging	<ol style="list-style-type: none"> <li>1. Bad connections can hinder the phone charging; ensure all contacts are correctly connected.</li> <li>2. Check to see whether the phone battery charging slot or the charger itself is damaged. If so, discontinue use. Replace battery or charger.</li> <li>3. The phone cannot be charged in temperatures below 10°C or above 55°C.</li> </ol>
Does not dial numbers	<ol style="list-style-type: none"> <li>1. Confirm that once the number is entered using the keypad that the green call button is pressed to dial the phone number.</li> <li>2. Check the phone number entered is correct.</li> <li>3. Check reception coverage status of your mobile phone.</li> <li>4. Ensure the call restriction settings are correct in order for you to dial outgoing calls.</li> </ol>

## 14. Radio Frequency (RF) Exposure and SAR

This device meets international guidelines for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) radiation recommended by international guidelines (ICNIRP). These limits are part of the comprehensive guidelines and establish the permitted levels of RF energy for the general population. The guidelines were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The exposure standard for mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. Although the SAR is determined at the highest certified power level, the actual SAR of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the device.

SAR values may vary depending on national reporting and testing requirements and the network band. Use of device accessories and enhancements may result in different SAR values.

The SAR limit for mobile devices used by the public is 2.0 w/kg (watts per kilogram) averaged over 10 grams of body tissue. The guidelines incorporate a substantial margin of safety to give additional protection for the public and to account for any variations in measurements. The highest SAR Value - 0.743w/kg.

Check out our other fantastic range  
Of products at [www.ttfone.com](http://www.ttfone.com)