

TTfone Venus TT700

Quick Guide



1. Remove back cover from phone, by sliding it down.



2. Place SIM card under the metal holder, with the contact points facing down. A Micro SD memory card fits into the secondary slot.



3. Insert the battery ensuring the contact points of the battery are at the bottom, then replace cover.



4. To turn the handset on, press and hold the **RED** phone key for approximately 2 seconds.



5. To dial a number, enter the desired phone number on the keypad, and press the **GREEN** phone key, press the **RED** button to end the call.



6. Answer incoming calls by pressing the **GREEN** phone key.



7. To access your handset menu, press the menu button upwards.



8. To activate the torch feature, press and hold the volume (+) button for about 2 seconds. Repeat this step to turn this feature off.



9. To increase the caller ringtone volume, use the button on the left side. Press the top part of the button (marked +) to increase the volume & the bottom (-) to decrease.



10. To activate the FM radio, press and hold the volume (-) button for about 2 seconds, repeat this step to turn off this feature.

For further information please consult the manual provided or visit us at:

www.ttfone.com

Ver. 1.0